

# **Implementing FTP**

#### **Introduction**

FTP (File Transfer Protocol) is used for file sharing across devices.

## **Objectives**

In this project/lab the student will:

- Create an FTP site using Microsoft Internet Information Services (IIS)
- View the FTP Server files on a client
- Perform packet analysis


#### Resources

- VMware Workstation Pro
- Windows 10 ISO

## **Procedure**

#### Create an FTP Site

- 1. Open Win1oClient1 VM and sign in.
- 2. Open Control Panel, click Programs, then click Turn Windows Features on or off.
- 3. In the Windows Features dialog box, expand Internet Information Services and click FTP Server. Click OK. Click Close when the feature installation is complete.
- 4. Open Internet Information Services (IIS) Manager. Expand the left pane and right click Sites, then select Add FTP Site.



- 5. In the Add FTP site dialog box, type NerdifyentFiles as the FTP Site Name. Click the three dots to the right of the Physical Path box and navigate to C:\inetpub\ftproot. Click Next.
- 6. In the Binding and SSL settings dialog box, enter the following:

- a. IP Address: 192.168.143.100
- b. Port: 21
- c. Enable Start FTP site automatically
- d. Choose No SSL, then click Next.
- 7. In the Authentication and Authorization Information dialog box, choose Anonymous in the Authentication section. This ensures you do not need a username or password to access files on the FTP site.
- 8. In the Authorization section, allow access to all users. Check the box next to read permissions. This ensures users can't make changes to the site. Click Finish.
- 9. Open Windows Firewall with Advanced Security. In the left pane, click Inbound Rules. 10. Locate the three FTP Server rules. Right click each one and click Enable. Each rule should now have a checkmark to the left of it.

FTP Server (FTP Traffic-In)	FTP Server	All	Yes	Allow
FTP Server Passive (FTP Passive Traffic-In)	FTP Server	All	Yes	Allow
FTP Server Secure (FTP SSL Traffic-In)	FTP Server	All	Yes	Allow

#### Test the FTP Site

- 1. Open Win1oClient2 VM and sign in.
- 2. Open command prompt and access your FTP site by typing in ftp 192.168.143.100. You may need to press Enter twice.

```
C:\Users\Client1>ftp 192.168.143.100
```

3. When prompted, enter anonymous for the username and any email address for the password.

```
C:\Users\Client1>ftp 192.168.143.100

Connected to 192.168.143.100.

220 Microsoft FTP Service

200 OPTS UTF8 command successful - UTF8 encoding now ON.

User (192.168.143.100:(none)): anonymous

331 Anonymous access allowed, send identity (e-mail name) as password.

Password:

230 User logged in.

ftp>
```

4. At the ftp> prompt, type dir and press Enter. If prompted with a Windows Security Alert, click Allow Access. Right now our FTP folder is empty, so you won't see a list of items appear.

```
ftp> dir
200 PORT command successful.
125 Data connection already open; Transfer starting.
226 Transfer complete.
```

5. Create a test document and place it in the ftproot directory on WindowsClientVM1. Now return to Windows1oClientVM2 and run the dir command again. Notice the output of the dir command has changed.

```
200 PORT command successful.

125 Data connection already open; Transfer starting.

11-26-19 02:23PM 0 test.txt

226 Transfer complete.

ftp: 52 bytes received in 0.00Seconds 52000.00Kbytes/sec.
```

6. To disconnect from the FTP server and return to a normal command prompt, type bye and press enter.

## Capture HTTP Packets

- 1. Open Wireshark on Windows10ClientVM2 and begin a capture.
- 2. Repeat the process again to access your FTP site again via command prompt, then stop your Wireshark capture. Save the Capture as MyFTP\_Cap.pkt.
- 3. Use the green filter bar at the top of the window to show only FTP protocol packets by typing "ftp" and pressing Enter. Use this series of packets to answer the reflection questions.

#### Reflection

- 1. Was TCP or UDP used for the connection?
- 2. Locate and record the source and destination IP addresses.
- 3. To view the full conversation between the client and the server, right click the first FTP packet and select Follow then TCP Stream. Observe the conversation you had with the FTP server. Take a screenshot of this, noting that the password you typed in appears in plain text.
- 4. What user accessed the FTP server?
- 5. What password did this user input?
- 6. Note the three digit status codes associated with your interaction with the FTP server. What is indicated by each of them?

ı. 220 -	_
). 200 -	
2. 331 -	_
l. 230 -	
2. 332 -	_
. 125	_
v. 226 -	

h. 221 -			
11, 221 -			

7. Select the FTP-DATA packet. In the middle pane, scroll down until you see "Line-based text data (1 lines)" and expand it. At what date and time did you use the dir command on the FTP server?

## Rubric

Standards for This Competency	Point Value	
Submitted Wireshark Packet Capture MyFTP_Cap.pkt	16 points	
Correct answer to Question 1	10 points	
Correct answer to Question 2	10 points	
Correct answer to Question 3	10 points	
Correct answer to Question 4	10 points	
Correct answer to Question 5	10 points	
Correct answer to Question 6	24 points (8 points each)	
Correct answer to Question 7	10 points	