

# **Install RSAT and Join the Domain**

## Introduction and/or Background

TX-Rig Company wants all computers on the network to have a centrally managed security policy and for Administrators to be able to remotely manage company servers.



# Texas Rig, Inc.

Fueling The Future.

### **Objectives**

In this project/lab the student will:

- Install Remote Server Administration Tools (RSAT) on a Windows 10 client
- Install Dynamic Host Configuration Protocol
   (DHCP) and configure both IPv4 and IPv6 addresses to be assigned to clients
- Join your Windows 10 client to the domain

# **Equipment/Supplies Needed**

- VMWare Workstation Pro
- Windows Server 2019 Virtual Machine

## **Assignment**

As a member of the Server Administration Team, you want to be able to remotely manage your servers, assign IP addresses to workstations using DHCP, and ensure all workstations have a centrally managed security policy. To accomplish this, you will install the Remote Server Administration Tools, enable DHCP on your server, and join the workstation to the domain.

# Part 1A: Install the Remote Server Administration Tools (RSAT) on newer versions of Windows 10

- 1. Make sure your Windows 10 computer VM is activated
- 2. Make sure you have VMWare Tools installed.
- 3. Your network adapter should be set to "NAT" in VMWare settings
- 4. The Windows 10 VM should be set to DHCP.
- 5. You must have Internet access to install Windows Features.

- 6. Power on and login to your Client computer VM.
- 7. Open a command prompt and type **Ping 8.8.8.8**, to confirm you have Internet access.
- 8. Type Winver to confirm you are running Windows 10 version 1809 or later.
- 9. If you are running an earlier version of Windows, skip to Part 1B.
- Right-click the Start button, select Settings, click Apps, then select Optional Features.
- 11. Select **Add a Feature.** Select each of the following features and click **Install:** 
  - a. RSAT: Active Directory Domain Services and Lightweight Directory Services

    Tools
  - b. RSAT: DHCP Server Tools
  - c. RSAT: DNS Server Tools
  - d. RSAT: Group Policy Management Services
  - e. RSAT: Server Manager
- 12. Click the Left-Arrow in the upper left corner of the Add a Feature screen to go back to the Optional Features Screen to watch the RSAT Tools installation. Once the installs are finished, scroll down to the RSAT Tools and take a screenshot. (PrtScr#1)
- 13. If the RSAT feature is not available, use the install method in Part 1B.
- 14. Shut down and power off your Windows 10 VM.
- 15. With the Windows 10 VM powered off, select **Edit Virtual Machine Settings**.
- 16. Change your network adapter from NAT to Host-Only", then click **OK.**
- 17. Power on and login to your Client computer.
- 18. Proceed to Part 2 of this lab.

# Part 1B: Install the Remote Server Administration Tools (RSAT) on older versions of Windows 10

- 1. Login to your Client computer.as txrigXX\administrator.
- 2. **Drag and Drop** the RSAT install file to the Windows 10 VM from your host computer. (You could also download it from Microsoft) Right-click the .msi install file and select **Run as Administrator**. Follow the prompts to complete the install and then reboot, if needed.
- 3. (PrtScr#1) Take a screenshot of the installed RSAT Tools.
- 4. Shut down your Windows 10 client computer VM.
- 5. Change your network adapter from NAT to Host-Only", then click OK.
- 6. Power on and login to your client computer VM.

## Part 2: Disable DHCP for the "Host-only" network in VMWare Workstation

- 1. Before we power on our client, we need to disable the VMWare DHCP service:
  - a. On the VMWare Workstation menu, select Edit, then select Virtual Network Editor...
  - b. In the lower right, click **Change Settings**, then click **Yes** on the UAC prompt
  - c. Select the Host-only network, then uncheck **Use local DHCP service to distribute DHCP address to VMs** and click **OK**. (You may want to revert this setting after this lab is completed.)

#### Part 3: Install DHCP Role Service

- 1. Log on to your server as Administrator.
- 2. On the Server Manager screen, click on the **Manage** drop down menu and select **Add Roles and Features**.
- 3. On the **Before you begin** screen, click **Next**.
- 4. On the **Select installation type** screen, leave **Role-based or feature-based installation** checked and click **Next**.
- 5. On the **Select destination server** screen, make sure your server is selected and click **Next**.
- 6. In the **Select server roles** window, click **DHCP Server**, and then click **Next**.
- 7. A message box appears showing which features will be installed. Click **Add Features** and click **Next**.
- 8. On the **Select features** screen, click **Next**.
- 9. Click **Next** on the next screen.
- 10. Click Install.
- 11. Select to Complete DHCP Configuration
- 12. Click Next
- 13. Click Commit to Authorize the DHCP server
- 14. Click Close

# Part 4: Configure DHCP for IPv4

- 1. In Server Manager, select Tools, then DHCP
- 2. Expand DHCP Server, right-click IPV4, select New Scope, follow the wizard prompts to configure the following items:
- 3. Name: V4Scope-your last name
- 4. IP Range: 172.17.3.101 to 172.17.3.200
- 5. Subnet mask: 255.255.255.0

- 6. Add exclusions: 172.17.3.125 and 172.17.3.126. Prevent these addresses from being assigned to a client
- 7. Lease Duration: Accept the default of 8 days
- 8. DHCP Options: Router/Gateway: Set to 172.17.3.1.
- 9. DNS: 172.17.3.10
- 10. WINS Server, Next (No WINS server in use)
- 11. Activate scope: Yes
- 12. Click on **Address Pool** and take a screenshot (PrtScr#2)

## Part 5: Configure DHCP for IPv6

- 1. In Server Manager, select Tools, then DHCP
- 2. Expand DHCP Server, right-click IPV6, select New Scope, follow the wizard prompts to configure the following items:
- 3. Name: V6Scope-your last name
- 4. Scope Prefix: 2001:0:0:: /64
- 5. Add exclusion: Accept the default
- 6. Lease Duration: Accept the default
- 7. Activate scope: Yes
- 8. Take a screenshot of your IPv6 scope (PrtScr#3)

## Part 6: Verify the Windows 10 Client computer VM can get a DHCP address

- 1. Power on the client computer and login.
- 2. Open a command prompt
- 3. Type **ipconfig** to verify you have obtained an IPv4 DHCP address from the address pool.
- 4. Switch to the server and open DHCP Manager in Server Manager.
- 5. Expand the IPV4 scope and select Address Leases
- 6. Take a screenshot of the address leased to the client (PrtScr#4)

# Part 7: Deactivate the DHCP Scopes on your server

Misconfigured DHCP could possibly cause connectivity problems on your school network, so we will disable it at this time.

- 1. Log on to your server as Administrator.
- 2. Open DHCP Manager and expand the IPv4 and IPv6 scopes
- 3. Right-click your IPv4 scope and select Deactivate
- 4. Right-click your IPv6 scope and select Deactivate
- 5. (Notice how the Icons now have a red Down-Arrow)
- 6. Take a screenshot showing your DHCP scopes are deactivated (PrtScr#5)

# Part 8: Configure your Windows 10 Client with a static IP

- 1. Set the following static IP address settings for Ethernet0 on the Windows 10 VM:
  - a. IP Address = 172.17.3.15
  - b. Subnet mask = 255.255.255.0
  - c. Default Gateway = 172.17.3.1
  - d. DNS = 172.17.3.10

#### Part 9: Join the workstation to the domain

- 1. Make sure your computer name is **ClientXX**, where XX is your initials.
- 2. Start your Windows 2019 Server and log on as Administrator.
- 3. Switch back to your Windows 10 computer.
- 4. Open a command prompt and type **ipconfig**.
- 5. Take a screenshot of your new Windows 10 IP address configuration. (PrtScr#6)
- 6. Make sure you can ping the server from the Windows 10 computer. At the command prompt, type **ping 172.17.3.10** and press **Enter**.
- 7. Right-click the **Start** button, select **Run**, type **control panel** and click **OK**.
- 8. Select **System and Security,** then select **System**.
- 9. Under Computer name, domain, and workgroup settings click on the **Change** settings link.
- 10. On the **System Properties** dialog box, click the **Change** button.
- 11. In the **Member of:** box type in TxRigXX.local and click **OK**. (Replace XX with your initials.)
- 12. On the **Computer Name/Domain Changes** screen, for the User name, type: **txrigXX\administrator** and the password and click **OK**.
- 13. On the "Welcome to the txrigXX.local domain" pop-up box, click **OK**
- 14. Click **OK** again, click **Close**, then click **Restart Now**.
- 15. After the computer restarts, select **Other user** from the bottom left of the screen.
- 16. Type **txrigXX\Administrator** in the User name box and **Itnw1354** for the password and press **Enter**.
- 17. Open the Control Panel, select System and Security, then System.
- 18. Take a screenshot showing the full computer name and domain name. (PrtScr#7)
- 19. Close the **System** window.
- 20. Open DNS Manager (under **Windows Administration Tools**) on the Windows 10 client computer.
- 21. On the **Connect to DNS Server** screen, Select **The following computer,** type **srv19XX**, and click **OK**.

- 22. In the left pane, expand **srv19XX**, then expand **Forward Lookup Zones**, then click **txrigXX.local**.
- 23. Take a screenshot of the A record for clientXX (PrtScr#8).

# Part 10: Administrative Tasks – Using Server Manager on the Client Computer

- 1. Open Server Manager on the Client computer. Type **Server** in the Search box and select **Server Manager** from the list to open it.
- 2. Add your server to Server Manager. Right-click All Servers in the left pane and select Add Servers. Select your server from the list and click OK.
- 3. Take a screenshot as proof you are able to remotely manage your server (PrtScr#9).

#### Reflection

- What are the advantages and disadvantages of using the RSAT tools?
- Why do we join the client computer to the domain?

#### **Rubric**

## Checklist/Single Point Mastery

<u>Concerns</u> Working Towards Proficiency	<u>Criteria</u> Standards for This Competency	Accomplished Evidence of Mastering Competency
	Criteria #1: PrtScr#1 Take a screenshot of the installed RSAT tools (10 points)	
	Criteria #2: PrtScr#2 Take a screenshot of your IPv4 DHCP scope (10 points)	
	Criteria #3: PrtScr#3 Take a screenshot of your IPv6 DHCP scope (10 points)	
	Criteria #4: PrtScr#4 Take a screenshot showing your client's new DHCP address (10 points)	
	Criteria #5: PrtScr#5 Take a screenshot showing the IPv4 and IPv6 scopes are disabled (10 points)	
	Criteria #6: PrtScr#6 Take a screenshot showing the new static IP on your client computer (10 points)	

Criteria #7: PrtScr#7 Take a screenshot showing your client successfully joined to the domain (10 points)	
Criteria #8: PrtScr#8 Take a screenshot of the DNS A record for your Windows 10 Client (10 points)	
Criteria #9: PrtScr#9 Take a screenshot as proof you are able to remotely manage your server (10 points)	
Criteria #10: Answer reflection questions (10 points)	